

CCIECert-sec-30-RPC

2511>**rpc Access to Baytech RPC Power Switch**

```

RPC-3 Telnet Host
Revision F 4.20a, (C) 1999
Bay Technical Associates
Unit ID: RPC3-20
    
```

```

Enter username>rpc Login to RPC with username "rpc"
Login successful.
    
```

Selection Number	Outlet Name	Outlet Number	Power Status	
1	R1,2,3	1	On	Outlet numbers represent hardware to turn reboot, turn on, and turn off.
2	R4,5,6	2	On	
3	R7,8,9	3	On	
4	R10,11	4	On	
5	CAT1-CAT2	5	On (security rack only)	
6	FIREWALLS	6	On (security rack only)	
7	IPS-VPN	7	On	
8	PC1-PC2	8	On	

```

RPC3 Command Summary (F 4.20a).
"n" refers to Selection Number, as displayed in outlet status
LOGOUT      : terminate session
OFF n       : turn off outlet "n", do all for n = 0
ON n        : turn on outlet "n", do all for n = 0
REBOOT n    : cycle power off/on outlet "n", do all for n = 0
RC          : display outlet relay control info
STATUS      : display power status of outlets
HELP        : display this message
CLEAR       : Reset the maximum detected current
CURRENT     : Read the current
TEMP        : Read current temperature
    
```

Command Examples:

```

off          turn off everything
on           turn on everything
reboot       reboot everything
reboot 3     reboot routers R7, R8, R9
off 8        turn off PC1-PC2
on 5         turn on switches CAT1, CAT2
    
```