

2511>rpc **Access to Baytech RPC Power Switch**

RPC-3 Telnet Host
Revision F 4.20a, (C) 1999
Bay Technical Associates
Unit ID: RPC3-20

Enter username>rpc **Login to RPC with username "rpc"**
Login successful.

Selection Number	Outlet Name	Outlet Number	Power Status
1	R1,2,3	1	On
2	R4,5,6	2	On
3	R7,8,9	3	On
4	R10,11	4	On
5	CAT1-CAT2	5	On (security rack only)
6	FIREWALLS	6	On (security rack only)
7	IPS-VPN	7	On
8	PC1-PC2	8	On

Outlet numbers represent hardware to turn reboot, turn on, and turn off.

RPC3 Command Summary (F 4.20a).
"n" refers to Selection Number, as displayed in outlet status

LOGOUT : terminate session
OFF n : turn off outlet "n", do all for n = 0
ON n : turn on outlet "n", do all for n = 0
REBOOT n : cycle power off/on outlet "n", do all for n = 0
RC : display outlet relay control info
STATUS : display power status of outlets
HELP : display this message
CLEAR : Reset the maximum detected current
CURRENT : Read the current
TEMP : Read current temperature

Command Examples:

off turn off everything
on turn on everything
reboot reboot everything
reboot 3 reboot routers R7, R8, R9
off 8 turn off PC1-PC2
on 5 turn on switches CAT1, CAT2